



FCL30 Free Chlorine Tester

Revolutionary way to instantly get free chlorine value by using tri-electroded method measuring: faster and accurate, matching up to DPD results, without any reagent consuming. FCL30 in your pocket is a smart partner to measure free chlorine with you.



Typical Applications:



Waterworks



Drinking water



Swimming pool



Food hygiene

Main Features:

- Use tri-electroded method measuring: faster and accurate, matching up to DPD results.
- 2 points calibrate.
- MHX 4-Part-Design: firm comfortable grip, easy maintenance: no tools needed to change batteries or electrode.
- Large LCD with stored-energy backlight for easy meter information reading.
- 10 data sets memory stores and recalls.
- With 2x1.5V AAA batteries, more than 500 hours lifetime.
- Self-Diagnostic for easy troubleshooting (e.g battery indicator, message codes)
- Option: A530 regulator flow tank.

Specifications:

Range	0 -10.00 ppm
Resolution	0.01 ppm
Accuracy	±2% F.S.
Temp. Range	0 - 100°C / 32 - 212 °F
Calibration Point	2 points
Lock	Auto / Manual
Memory	10 sets
Electrode	CS5930
Auto power off	6 minutes no key is pressed
Protection	IP67
Power	2X1.5 V AAA batteries
Dimensions	164*37*40 mm
Weight	100g

FCL30A :
FCL30 Tester with CS5930 Electrode + CP300 Pouch